



Xcluder® Wrap Installation Instructions

Use for Part #s: 162800, 162801, 162802

Thank you for your purchase of **Xcluder® Wrap**, the best way to stop gnawing, clawing pests from damaging wires, cables, pipes, and other fixtures in homes and businesses.

Xcluder Wrap is as effective as Xcluder Fill Fabric at keeping pests at bay for applications other than gap filling.

 **Always wear hand and eye protection when installing Xcluder® products**

 **Repair any damaged wiring / insulation before installing Xcluder®**

Before You Begin:

Make sure the object to be protected is clean and dry

Choose the correct width of Xcluder Wrap:

2" width for protecting thin objects like wires and small cables.

4" widths for protecting larger objects like A/C lines and smaller diameter pipes.

8" width for big jobs such as soffits and gables.

Folding Wrap Method - For Protecting Wires, Cables and Small Pipes

1. Measure and cut Xcluder® Wrap to the length of the object to be protected.
2. Start at one end*, peeling the backing off Xcluder Wrap and pressing it to the object to be protected, parallel to the direction of the wire/cable/pipe.
3. Fold Xcluder Wrap over onto itself, with the wire/cable/pipe sandwiched in between.

***One corner of the release paper has been pre-peeled for ease of separation. This corner may have shifted during shipping, however it is still easier to identify this corner and begin removal of backer paper from this location. NOTE: Carefully separate the backer paper from the adhesive layer. DO NOT pull the adhesive layer off with backer paper. Adhesive layer MUST remain attached to Xcluder fabric.**



Version—BG 0620



Xcluder® Wrap Installation Instructions

Use for Part #:162800, 162801, 162802

Helical Wrap Method - For protecting multiple objects

1. Peel back about 6" of the backing paper to expose the adhesive backing*
2. Starting at one end, align the Xcluder® Wrap so that it is perpendicular to the object to be protected
3. Attach the Xcluder® wrap to the object by pressing firmly
4. Make one complete wrap, then continue wrapping in a helical (corkscrew) fashion along the length of the object being protected. There should be a slight overlap after each wrap to ensure there are no exposed, vulnerable surfaces.

***One corner of the release paper has been pre-peeled for ease of separation. This corner may have shifted during shipping, however it is still easier to identify this corner and begin removal of backer paper from this location. NOTE: Carefully separate the backer paper from the adhesive layer. DO NOT pull the adhesive layer off with backer paper. Adhesive layer MUST remain attached to Xcluder fabric.**



It is often easier to peel the backing as you work rather than all at once



When you complete a project, leave a corner of the backing folded back to make it easier to start the next time

For Protecting Flat Surfaces like Soffits and Gables

Simply peel and stick Xcluder® Wrap directly to the area to be protected.

Version—BG 0620